

# Gulvask: Fugtmetode Floor-washing: Damp method

## Metodekort

1

### Puri-Line Universal til daglig rengøring uden pleje.

*Puri-Line Multi-purpose cleaner for everyday cleaning without care.*

### Puri-Line Vaskepleje til periodisk rengøring med pleje.

*Puri-Line Floor cleaning and care for periodic cleaning with care.*



165516



165517



168867

### Dosering:

**5 ml til 2 liter vand**

*Dosage:*


*5 ml to 2 liters of water*

**10 stk. 40 cm mopper**

**2 l sæbeopløsning**


*10 pcs 40 cm mops*

*2 l solution of water and soap*



1000011289

2



### Fyld din spand med den korrekte mængde vand.


*Fill your bucket with the correct amount of water.*



### Tøm doseringsenheden med din kemi i spanden med vand.

*Empty the dilution unit with your chemical into the bucket with water.*

3



### 1 Sæt mopperne på højkant i en anden spand.

*Place the mops upright in another bucket.*

### 2 Tilføj halvdelen af vandet.

*Add half of the water.*

### 3 Mopperne vendes, og resten af vandet tilføjes.

*Turn the mops and add the rest of the water.*

### 4 Efter 3–5 minutter vendes mopperne, så velcroen vender opad. Mopperne er nu klar til brug.

*After 3–5 minutes, flip the mops so the Velcro faces up. The mops are now ready for use.*


4



### Vask gulvet 20–25 m<sup>2</sup> afhængig af gulvtype og besmudsning.

*Wash the floor 20–25 m<sup>2</sup> depending on level of dirt and floor type.*

5



### Den snavsede moppe smides til vask og en ny moppe sættes på.

*Put the dirty mop in the laundry and use a new mop.*

