

Skumrengøring – afkalkning Foam cleaning – descaling

Metodekort



1000001455



Vælg den brune dyse for korrekt dosering.

Select the brown nozzle for correct dosage.

1



Skyl overfladen grundigt med koldt vand.

Rinse the surface thoroughly with cold water.

2



Hæld koncentreret skum i beholderen. Anvend den brune dyse (2% blanding).

Pour undiluted foam in the container. Use the brown nozzle (2% mixture).

3



Skum overfladen nedefra og op.

Foam the surface from the bottom to the top.


4



Anvend en skrubbe nedefra og op.

Use a scrub from the bottom to the top.

5



Lad sæben virke i minimum 10 minutter.

Let the soap work for at least 10 minutes.

6



Skyl grundigt med koldt vand oppe fra og ned.

Rinse thoroughly with cold water from the top and down.

7



Tør efter med en inventarmoppe.

Wipe with an inventory moppe.